
Energy Management Energy Analyzer Type EM112



- Compliant with the international accuracy standard IEC/EN62053-21, and the IEC/EN61557-12 performance requirements (active power and active energy).
- Certified according to MID Directive (option PF only): see "how to order" below

- Single phase energy analyzer
- Class 1 (kWh) according to EN62053-21
- Class B (kWh) according to EN50470-3
- Accuracy ±0.5% RDG (current/voltage)
- Direct current measurement up to 100AAC
- · Backlit LCD display (3x 8-digit) with integrated touch key-pad
- Energy readout on display: 8 digit
- · Variable readout on display: 4 digit
- Energy measurement: kWh and kvarh (imported/exported); kWh+ by 2 tariffs
- System variables, kW, kvar, V, A, PF, Hz, kWdmd, kWdmd peak
- Self power supply
- Dimensions: 2-DIN module
- Protection degree (front): IP51
- Pulse output (optional, by open collector PNP)
- RS485 Modbus port (optional)
- M-bus port (optional)
- Digital input (for tariff management)
- · Easy connection or wrong current direction detection

Product description

Single-phase energy analyzer with backlit LCD display with integrated touch keypad. Particularly indicated for active energy metering and for cost allocation in applications up to 100 A (direct connection), with dual tariff management availability. It can measure imported and exported energy or be programmed to consider only

MID Certified according to MID Directive, Module B and Module D of Annex II, for legal metrology relevant to active electrical energy meters (see Annex V,

MI003, of MID). Can be used for fiscal (legal) metrology.

the imported one. Housing for DIN-rail mounting, with IP51 front degree protection. The analyzer is optionally provided with pulse output proportional to the active energy being measured, RS485 Modbus port or M-bus port.

How to order

EM112-DIN AV0 1 X O1 PF B

Model	
Range code	
System	
Power supply	
Output	
Option	
Measurement ——	

Type Selection

Range code System			Power supply		Output		
AV0:	230VLN AC - 5(100)A (Direct connection)	1: 1-phase	e 2-wire	X :	Self power supply -30% +20% of the rated measuring input voltage, 50Hz	O1: S1: M1:	pulse output RS485 Modbus port M-bus port
Optic	n			Meas	surement		
PF:	Certified according to MID Directive. Can be used for fiscal (legal) metrology.		n be used for	A:	The power is always in positive imported and n the total energy meter i	egative	e exported power) and
				B:	Only the total positive e according to MID.	energy	meter is certified

CARLO GAVAZZI



	How to order	EM112-DIN AV0 1 X O1 X
STANDARD Not certified according to MID Directive. Cannot be used for fiscal (legal) metrology.	Model Range code System Power supply Output Option	

Type Selection

Rang	e code	Syst	tem	Pow	er supply	Outp	ut
	230VLN AC - 5(100)A (Direct connection) 120VLN AC - 5(100)A (Direct connection).	1:	1-phase 2-wire	X:	Self power supply -30% +20% of the rated measuring input voltage, 45 to 65Hz	O1: S1: M1:	pulse output RS485 Modbus port M-bus port
Ontio	Available on request (MOQ 100 pcs)						
Optio	n						

X: none

Input specifications

Rated Inputs		Displa
Current type	1-phase loads, direct	Туре
	connection	-
Current range	5(100)A	Read
Nominal voltage	230VLN AC (AV0 option),	Taua
Accuracy	120 VLN (AV1 option)	Touc Max. a
(@25°C ±5°C, R.H. ≤60%,		Ener
45 to 65 Hz)		LIG
AV1	Imin=0.25A; Ib: 5A, Imax:	Varia
	100A; Un: 120VLN -30%	
	+30%	Memo
AV0	Imin=0.25A; Ib: 5A, Imax:	Ener
	100A; Un: 230VLN -30%	
	+20%	
Energies		Prog
Active energy	Class 1 according to	
	EN62053-21 (in AV0	
	version, class 1 accuracy	
	is guaranteed also at 120 VLN)	LEDs
	Class B (kWh) according to	
	EN50470-3	
Reactive energy	Class 2 according to	
· · · · · · · · · · · · · · · · · · ·	EN62053-23	
Start-up current:	40mA (AV0, AV1), positive	
	or negative	
	Self-consumption is not	
	measured.	
Start-up voltage	84VLN (AV1), 161VLN	Curre
	(AV0)	Cont
Resolution Current	Display 0.1 A	For 1
Voltage	0.1 V	Voltag
Power	0.01 kW or kVar	Cont
Frequency	0.1 Hz	For 5
PF	0.01	Input
Energies (positive)	0.01 kWh or kvarh	Volta
Energies (negative)	0.01 kWh or kvarh	Volta Curre
	Serial communication	Curre
Current	0.001 A	
Voltage	0.1 V	
Power	0.1 kW or kvar	
Frequency PF	0.1Hz 0.001	
Energies (positive)	0.001 kWh or kvarh	
Energies (negative)	0.001 kWh or kvarh	
Energy additional errors		
Influence quantities	According to EN62053-21	
Temperature drift	≤200ppm/°C	
Sampling rate	4096 samples/s @ 50Hz	
	4096 samples/s @ 60Hz	

Display and touch key-pad	
Туре	Backlit LCD, 3 rows by
	8-digit each, h 5 mm
Read-out	Energy: 8 digit. Variables: 4
-	digit
Touch key Max. and Min. indication	2 (Enter/DOWN and UP).
	May 00 000 000
Energies	Max. 99 999 999 Min. 0.01
Variables	Max. 9999
valiables	Min. 0.01
Memory energy storage	WIII. 0.01
Energy	10^10 cycles. Energy value
Energy	is saved every time the less
	significant digit increases.
Programming parameters	10 ¹ 0 cycles. When a
r regramming parametere	parameter is modified, only
	the relevant memory cell is
	overwritten
LEDs	Flashing red light pulses
	according to EN50470-3,
	EN62052-11, 1000 imp./
	kWh (min. period: 90ms,
	max. frequency: 11 Hz)
	Fix orange light: wrong
	current direction (only with
	PFB option or with "B"
	measurement selection in
	case of X option)
	. ,
Current overloads	
Continuous	100A, @ 50Hz
Continuous For 10ms	
Continuous For 10ms Voltage Overloads	100A, @ 50Hz 3000 A
Continuous For 10ms Voltage Overloads Continuous	100A, @ 50Hz 3000 A 1.2 Un
Continuous For 10ms Voltage Overloads Continuous For 500ms	100A, @ 50Hz 3000 A
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance	100A, @ 50Hz 3000 A 1.2 Un
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm
Continuous For 10ms Voltage Overloads Continuous For 500ms Input impedance Voltage input 230VL-N Voltage input 120VL-N	100A, @ 50Hz 3000 A 1.2 Un 2 Un 1.2Mohm 1.2Mohm



Digital input specifications

Digital inputs Function	Voltage free contact Tariff management (digital input between 7-8 terminals)	Overload
Number of inputs Contact measurement voltage Input impedance Contact resistance	1	

100kohm, open contact In case a voltage is erroneously applied to the digital input, the input is not damaged up to 30 V ac/dc.

Output specifications

RS485 serial port	RS485 by screw connection.	Other	Available functions: wild card, header, initialisation
Function	For communication of measured data, programming parameters		SND_NKE, and req_udr management. Management of primary address
Protocol	Modbus RTU (slave function)		modification via M-bus. VIF, VIFE, DIF and DIFE:
Baud rate	9.6, 19.2, 38.4, 57.6, 115.2		see protocol
	kbaud, even or no parity,	Static output	
Address	1 to 247 (default: 1)	Purpose	For pulse output
Driver input capability	1/8 unit load. Maximum 247 transceivers on the same		proportional to the active energy (kWh)
	bus.	Pulse rate	Selectable in multiple of
Data refresh time	1s		100
Read command	50 words available in 1		Max 500 or 2000
	read command		pulses/kWh according to
Rx/Tx indication	Rx segment on display		pulse ON duration
	is shown when a valid	Pulse ON duration	Selectable: 30ms or
	Modbus command is sent		100 ms according to
	to that specific meter;		EN62052-31
	Tx segment on display	Output type	open collector PNP
	is shown when a valid	Load	V _{on} 1 V dc max. 100mA
	Modbus reply is sent back		V _{OFE} 80 V dc max.
	to the master		0.11
M-bus port	M-bus by screw		
	connection.		
Function	For communication of		
	measured data		
Protocol	M-bus according to		
	EN13757-3		
Baud rate	0.3, 2.4, 9.6 kbaud		
Meters in the M-bus network	250		
Primary address	Selectable		
Secondary address	Univocally defined in each		
-	unit		
Secondary address range	from 7000 0000 to 7999 9999		

General specifications

Operating temperature	-25 to +65 °C, indoor,	Housing	
	(R.H. from 0 to 90% non-	Dimensions (WxHxD)	35 x 63 x 90 mm
	condensing @ 40°C)	Material	PTB, self-extinguishing: UL
Storage temperature	-30°C to +80°C (R.H. <		94 V-0
	90% non-condensing @	Sealing covers	Included
	40°C)	Mounting	DIN-rail
Overvoltage category	Cat. III	Protection degree	
Insulation (for 1 minute)	4000 VAC RMS between	Front	IP51
	measuring inputs and	Screw terminals (cable inputs)	IP20
	digital/serial output (see table) 4000 VAC RMS	Weight	Approx. 160 g (packing included)
Dielectric strength	4000 VAC RMS for 1 minute		
EMC	According to EN62052-11		
Standard compliance			
Safety	EN62052-11		
Metrology	EN62053-21, EN50470-3		
	IEC/EN61557-12 (active		
	power and active energy, MID models only)		
Approvals	CE, UKCA, MID (PF option only), UL (AV1 model only)		
Connections			
Cable cross-section area	Measuring inputs: max. 25 mm ² , min. 5 mm ² with/ without metallic cable ferrule; Max. screw tightening torque: 2.8 Nm		
Other terminals	1.5 mm ² , Min./Max. screws tightening torque: 0.5 Nm		

Power supply specifications

Self power supply		Power consumption	≤ 1W. ≤ 8VA
AVO	230VAC VL-N, -30% +20%	••••	, -
	45-65Hz		
AV1	120VAC VL-N, -30% +30%		
	45-65Hz		


Insulation (for 1 minute) between inputs and outputs


	Measuring input	Digital or serial output	Digital input
Measuring input	-	4 kV	4 kV
Digital or serial output	4 kV	-	0 kV
Digital input	4 kV	0 kV	-



Accuracy (according to EN50470-3 and EN62053-23)

kWh, accuracy (RDG) depending on the current





Measurement accuracy according to IEC/EN61557-12 (MID versions)

Active power

Performance class 1

Active energy

Performance class 2

MID compliance (PF option only)

Accuracy	$0.9 \text{ Un} \le U \le 1.1 \text{ Un}; 0.98 \text{ fn} \le f \le 1.02 \text{ fn}; \text{ fn}: 50 \text{ Hz};$ $\cos\varphi: 0.5$ inductive to 0.8 capacitive. Class B Considering listed Ib or In values
Operating temperature	-25 to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C)
EMC compliance	E2
Mechanical compliance	M2

Display pages

No	1 st row	2 nd row	3 rd row	"Full" mode	"Easy" mode	Note
0	kWh+ (imported)		kW	Х	Х	In PF version (MID) this is the only certified energy meter. In PFA version and in X version with Measurement menu set to "A", this is considering the total energy without considering the current direction.
1	kWh- (exported)		kW	Х	Х	In PFB version and in X version with Measurement menu set to "B"
2	kWh+ (imported)		V	Х	Х	
3	kWh+ (imported)		A	Х	Х	
4	kWh+ (imported)		PF	Х		
5	kWh+ (imported)		Hz	Х		
6	kvarh+ (imported)		kvar	Х		In PFA version and in X version with Measurement menu set to "A", this is considering the total positive reactive energy without considering the current direction.
7	kvarh- (exported)		kvar	Х		In PFB version and in X version with Measurement menu set to "B"
8	kWh+ (imported)	kWdmd peak	kWdmd	Х		
9	kWh (t1)	"t1"	kW	Х	Х	Only relevant to kWh+, with Tariff menu set to ON.
10	kWh (t2)	"t2"	kW	Х	Х	Only relevant to kWh+, with Tariff menu set to ON.

X= available



List of available menus

Menu name and desc	ription	Range	Default setting	
PASS	Password request From 0000 to 9999		0000	
nPASS	New password	From 0000 to 9999	0000	
Measure	Measurement type (A=easy connection; B=bidirectional, imported and exported energy). Not available in PFA and PFB versions (MID)	A; b	A	
P int	Integration time for Wdmd calculation	1 to 30 min	1	
Mode	Selection of complete or simplified set of variables on display	Full or Easy	Full	
Tariff	Tariff enabling	Yes/No	No	
Home	Home page selection (default page at power-on and after 120 s time-out from other pages). Not available in PFA and PFB versions (MID).	0 to 10	0	
PULSE (O1 option)	Selection of pulse ON duration	30 or 100 ms	30	
	Selection of the pulse weight (multiples of 100 pulses/kWh)	100 to 500 (if duration is 100ms) 100 to 2000 (if 30 ms)	100	
Address (S1 option)	Modbus serial address	1 to 247	01	
Kbaud (S1)	Modbus baud rate	9.6; 19.2; 38.4; 57.6, 115.2 kbps	9.6	
ParltY (S1)	Modbus parity	No/even	No	
	Stopbit (available only if parity is set to "No")	1;2	1	
Prl Add (M1 option)	M-bus primary address	1 to 250	0	
Kbaud (M1)	d (M1) M-bus baud rate		2.4	
RESET	Allow the reset of tariff meters and W dmd peak (kWh/kvarh meter reset available only via serial communication)	Yes/No	No	
End	Exit to measuring mode			

Note: after the confirmation of a new parameter value, the value is stored in the memory without the need to exit the programming mode.


Page	Code	Description				
YEAr	InFO 1	Year of manufacture				
SErIAL n	InFO 2	Serial number, corresponds to the one indicated on the front print				
rEVISIon	InFO 3	Firmware revision – XY.nn:				
PuLS Led	InFO 4	Front LED pulse weight				
MEASurE	P3	Measurement type (only X option)				
P int	P4	Requested average power calculation interval				
ModE	P5	Display mode				
tArlFF	P6	Tariff management enabling and current tariff				
HoME	P7	Measurement page set as home page (only X option)				
CHEkSuM	InFO 6	Firmware checksum				
Pages specific to the S1 version						
AddrESS	P10	Modbus address				
bAUd	P11	Baud rate				
PArITY	P12–1	Parity				
StoP bit	P12–2	Stop bit				
Pages specific to the O1 version						
PULSE	P8–1	Duration				
PuL rAtE	P8–2	Pulse weight				
Pages specific to the M1 version						
Pr I Add	P9	M-Bus primary address				
bAUd	P11	Baud rate				
SEC Add	InFO 5	M-Bus secondary address, univocal and set during production				


Additional available information on the display (*)


(*) can be reached by pressing simultaneously the 2 touch keys





Wiring diagrams














Front panel description



- Display Backlit LCD display with touch key-pad. Right key: enter, down Left key: up
- 2. LED LED proportional to kWh reading
- 3. Serial number and MID data Area reserved to serial number and MID-relevant data in PF versions

Dimensions (mm)

