Photoelectrics Amplifier Type S142B..



S142 B RNN 924



Product Description

µ-Processor controlled amplifier for one set of photoelectric sensors, type MOFTR. Utilising an 11-pin circular plug for easy connection.

8 A SPDT relay output, NPN / PNP transistor output or alarm output. Diagnostics for sensor test during operation. Alignment help via LED or alternation of alarm output. Level indication for dirt accumulation. Manual or automatic emitter power regulation. Two emitter codes available for high neighbour immunity. ON- or OFF delay adjustable up to 10 sec.

٠	µ-Processor	controlled
---	-------------	------------

- · Amplifier relay for photoelectric switches
- Automatic or manual emitter power regulation
- Self-diagnostic functions
- Alignment help
- Rated operational voltage: 24 VAC/DC, 24 VAC, 115 VAC or 230 VAC
- Output 8 A/250 VAC SPDT relay and 100 mA NPN
- LED indication: Automatic gain, output, level, emitter or receiver fault

((91) ()

Ordering Key

Type Special function -**Output type** (R-Relay, N-NPN, P-PNP, T-Test)

Power supply -

Type Selection

Function	Ordering no.	Ordering no.	Ordering no.	Ordering no.
diameter	Supply: 24 VAC/DC	Supply: 24 VAC	Supply: 115 VAC	Supply: 230 VAC
NPN output & Test input	S142 B RNT 924	S142 B RNN 024 ¹⁾	S142 B RNT 115	S142 B RNT 230
NPN output & Alarm output	S142 B RNN 924 ¹⁾		S142 B RNN 115 ¹⁾	S142 B RNN 230 ¹⁾
PNP out., PNP Alarm & Test	S142 B PPT 924		S142 B PPT 115	S142 B PPT 230

All amplifiers is with ON & OFF delay

Specifications

Rated operational voltage (U₀) Pins 2 & 10 230 115 024 924 924	195 to 265 VAC, 45 to 65 Hz 98 to 132 VAC, 45 to 65 Hz 20.4 to 27.6 VAC, 45 to 65 Hz 20.4 to 27.6 VAC/DC Class 2	Test input (Mute) Emitter Enabled Emitter Disabled Imax @ 40 VDC	NPN PNP > 5.0 VDC < V _{CC} - 3 VDC < 3.0 VDC > V _{CC} - 5 VDC 1 mA
Rated operational power AC supply	3.3 VA 1.6 VA / 1.4 W	Protection output transistor	Reverse polarity, short circuit and transients
AC/DC supply Delay on operate (t _v)	< 300 mS	Supply to sensors Emitter	Pins 5 & 7
Outputs Relay Rating (AgCdO) Resistive loads AC1 DC1 or Electrical life (typical) AC1 Transistor output data Output current Output function Relay Transistor Alarm	μ (micro gap) 8 A / 250 VAC (2500 VA) 0.2 A / 250 VDC (50 W) 2 A 25 VDC (50 W) > 100.000 operations < 100 mA @ 40 VDC (max. load capacity 100 nF) < 2,5 VDC @ 100 mA Make or break on DIP-switch SPDT NPN / PNP, 100 mA, 40 VDC NPN / PNP, 100 mA, 40 VDC Delay on alarm 10 sec	Supply voltage (open loop) Current Output resistance Receiver Supply voltage (open loop) Short-circuit current Input resistance	15 V square wave < 450 mA, short circuit protected 10 Ω Pins 6 & 8 5 VDC 10 mA 470 Ω

CARLO GAVAZZI

Specifications

Emitter power Power Adjustment	Settings on DIP switch no 4, 50 % or 100 % range	Transistor output Response time OFF-ON (t _{ON}) ON-OFF (t _{OFF})	5 Hz min delay 0.1 – 10 s 0.1 – 10 s
Manual Automatic (Auto LED ON) Sensing distance	240° Potentiometer Potentiometer settings to minimum Maximum range indicated on	Environment Overvoltage categoty Degree of protection Pollution degree	III (IEC 60664) IP 20 /IEC 60529, 60947-1) 3 (IEC 60664/60664A, 60947-1)
Rated insulation voltage (U)	photoelectric switch data- sheets in 100 % settings 250 VAC	Temperature Operating Storage	-20° to +50°C (-4° to +122°F) -50° to +85°C (-58° to +185°F)
Dielectric voltage	>2.0 KVAC (rms) (contacts / electronics)	Housing material	NORYL SE1, light grey
Rated impulse withstand volt	1 1	Weight AC supply AC/DC supply	200 g 125 g
Operating frequency (f)		Approvals	UL508, UL325, CSA
Light / Dark ratio 1:1 Relay output	5 Hz min delay	CE marking	EN12445, EN12453, EN12978

Specifications

Diagnostic

If a fault occurs on either the emitter or receiver the Alarm LED and output will turn ON.

Emitter fault

at a rate of 4 Hz.

During normal operation the receiver is monitored for faults. If the wires are short-circuited the "Code A, Yellow LED" flashes at a rate of 2 Hz. If the wires are broken the "Code A, Yellow LED" flashes

Receiver fault

During normal operation the emitter is monitored for faults.

If the wires are short-circuited the "Code B, Green LED" flashes at a rate of 2 Hz. If the wires are broken the "Code B, Green LED" flashes at a rate of 4 Hz.

Alignment

If the alignment DIP switch is set the Yellow Signal LED Flashes according to the signal quality.

Low frequency means weak signal.

Steady indication means maximum signal. On long distance it is not possible to get a steady signal but the alignment is optimal when the led flashes with the highest frequency.

On short distance the emitter power can be reduced using the potentiometer and then get better readings in the alignment LED. The ALARM output will fol-


low the Signal LED in align-

ment mode, so a Sensor tester (optional) can be connected to serve as a remote induction during alignment of the sensors.

NB! In alignment mode the output is off.


Code A or B

When two sensor pairs are mounted close to each other it is recommended to select one set to Code A and the other to Code B to avoid crosstalk.




²⁾ Switching function selected by DIP-switch, inverted function on pin 1, 4

Dimensions



Wiring Diagram



Connection to sensortester

Connection to sensortester ST-03 for alignment

	Sensortester		
	-	Signal	+
RNT Pin no.	10	9	
RNN Pin no.	10	11	
PPT Pin no.		9	2

Accessories

- 11 pole circular socket ZPD11 ΗF
- Holding down spring
- Mounting rack SM13
- Front panel mounting bezel FRS2

Delivery Contents

- Amplifier
- Packaging: Carton box

